

Technical datasheet

AZ® Remover 910

APPLICATIONS

Resist removal

- Designed to strip and dissolve negative-tone chemically amplified crosslinked resists
- Very effective at removing and dissolving positive-tone photoresists such as DNQ/Novolac and chemically amplified


Type of Resist	Cleaning Performance	
	Resist Strip	Resist Dissolution
Positive-Tone DNQ/Novolac (AZ P4620)	Yes	Yes
Positive-Tone Chemically Amplified (AZ 3DT-315)	Yes	Yes
Negative-Tone Chemically Amplified (AZ 15 nXT, AZ nLOF)	Yes	Yes

- Suitable for processes where sensitive metals and other materials are exposed; low etch rates on:
 - Al, Cu, Ti, W, TiW, TiN, Sn, Ni
 - Si, SiO₂

GENERAL PROPERTIES

Chemistry

- Solvent based product, contains acids
- EH&S friendly: acceptable in Europe
 - DPGME based
 - No NMP, DMAC, DMSO, TMAH
 - Amine free
- Acidic pH
- General composition
 - Organic solvents: penetrate, swell, and dissolve organic resist/residues
 - Acids: aid in breaking down the resist and dissolving it.



GENERAL PROPERTIES

Process Conditions


- Typical process flow



- AZ Remover 910 is water miscible: can directly go to a DIW rinse
- IPA is not recommended as an intermediate rinse
 - If IPA is used as a rinse it must be followed by DIW

Process Tools


- Suitable for use in batch immersion tools (wet benches)
 - Recommended process flow is to use a 2 tank set-up:



- Split the total strip time between the two AZ Remover 910 tanks
- 2 tank system minimizes resist re-deposition on the wafers: majority of resist comes off in first tank; 2nd tank removes remaining resist and prevents resist from re-depositing
- It is recommended that the AZ Remover 910 tanks be recirculated and filtered
- Any possible agitation beyond the normal recirculation of the fluid is recommended
- Suitable for use in batch spray tools as well
- Suitable for use in Veeco tools (immersion/high pressure spray combination)

Process Tools: Compatibility for Materials of Construction

- Compatible materials
 - PTFE
 - 316L EP stainless steel
 - Quartz
- Incompatible materials
 - Viton




PERFORMANCE DATA


Stripper	Positive Resist Platform	Resists	Process Conditions			Temp. 60°C for 5 min	
			Substrate	HB	FT (μm)	Resist Removed	Resist Dissolved
AZ® Remover 910	Positive Chem Amplified	AZ® 3DT-315	Si	None	12.6	YES	YES
	Positive Novolak	AZ® P4620	Si	None	12.4	YES	YES
			Process Conditions			Temp. 60°C for 5 min	
	Negative Resist Platform	Resists	Substrate	HB	FT (μm)	Resist Removed	Resist Dissolved
	Negative Cross Linked	AZ®15nXT	Cu	None	11.0	YES	YES
	Negative Cross Linked	AZ nLOf 2070	Si	None	7.8	YES	YES

Stripping Results with AZ® Remover 910, 60°C, 5 minutes AZ® 15 nXT Resist on Cu wafer


Substrate : 8 inch Cu wafers
Resist : AZ® 15 nXT
Film Thickness : 11 μm
Exposure : Suss Aligner @ 900 mJ/cm²
Soft Bake : 110°C/180 sec
PEB : 120°C/60 sec
Development : 2 x 60 sec in AZ® 300 MIF
Hard bake: : None



- AZ® Remover 910 removed and dissolved AZ® 15 nXT from Cu wafer at 60°C within 5 min -
 → Resist pieces dissolved in solution




Stripping Results with AZ® Remover 910, 65°C, 10 min AZ® 15 nXT Resist on Electroplated Cu wafer



- AZ Remover 910 removed and dissolved the 15nXT without etching the exposed Cu line

Stripping Results with AZ® Remover 910, 60°C, 5 minutes AZ® nLOF 2070 Resist on Si wafer

Substrate : 8 inch Si wafers
Resist : AZ® nLOF 2070
Film Thickness : 7.8 µm
Exposure : Suss Aligner @ 200 mJ/cm²
Soft Bake : 110°C/90 sec
PEB : 110°C/90 sec
Development : 1 x 90 sec in AZ® 300 MIF
Hard bake: : None




- AZ® Remover 910 removed and dissolved AZ® nLOF 2070 from Si wafer at 60°C within 5 min → Resist pieces dissolved in solution

Stripping Results with AZ® Remover 910, 60°C, 5 minutes AZ® P4620 Resist on Si wafer

Substrate : 8 inch Si wafers
Resist : AZ® P4620
Film Thickness : 12.4 µm
Exposure : Suss Aligner @ 600 mJ/cm²
Soft Bake : 110°C/240 sec
Development : 4 x 60 sec in AZ® 300 MIF
Hard bake: : None




- AZ® Remover 910 removed and dissolved AZ® P4620 from Si wafer at 60°C within 5 min → Resist pieces dissolved in solution



Stripping Results with AZ® Remover 910, 60°C, 5 minutes AZ® 3DT-315 Resist on Si wafer

Substrate : 8 inch Si wafers
Resist : AZ® 3DT-315
Film Thickness : 12.6 µm
Exposure : Suss Aligner @ 400 mJ/cm²
Soft Bake : 110°C/300 sec
PEB : 110°C/60 sec
Development : 2 x 60 sec in AZ® 300 MIF
Hard bake : None



- AZ® Remover 910 removed and dissolved AZ® 3DT-315 from Si wafer at 60°C within 5 min
→ Resist pieces dissolved in solution

Etch Rates

- Low etch rates on many common metals and materials

Etch Rates of AZ Remover 910 at 80°C (Å/min)

Al	Cu	Ti	W	TiW	TiN	Sn	Ni	GaAs
< 1	< 1	<1	1	< 1	5	< 1	< 1	45*

* Remover 910 GaAs etch rate quickly decreases as the remover heats. After 2 hours of heating at 60°C, the GaAs etch rate at 60°C dropped to < 1 Å/min

- Etch rates determined by using a Jandel 4 point probe to measure the metal film thickness

Bath Life

- Is usually limited by resist loading/saturation effects
 - At some point it will not be able to dissolve any more resist
- Saturation effects will be dependent on many factors
 - Type of resist
 - Resist thickness
 - Resist processing parameters (bakes, exposures, plasma etches, etc)
 - # of wafers processed
 - % coverage of resist on the wafers
 - Temperature of the AZ Remover 910
- Bath life is best determined by performing the test at the customer site
 - Most accurate results since the customer's materials, equipment, and processes are used



AZ® Remover 910 Bath Life Data

Wafer processing conditions

Resist:	AZ® P4620
Resist platform:	Positive-tone, DNQ/Novolak
Film thickness:	12.6 µm
Soft bake:	110°C x 240 sec
Pattern:	None, 100% coverage
Edge exclusion:	none
Exposure dose:	unexposed
Substrate:	8" HMDS-primed Silicon

Remover bath conditions

Temperature:	80°C
Volume:	150 mL in 250mL beaker
Agitation:	300 RPM stirring

Able to clean 10 full wafers by dissolution of resist in 150mL of AZ® Remover 910. This is equivalent to **>250 8" wafers fully covered with resist per gallon of AZ® Remover 910.**

AZ® Remover 910 Bath Life Data

Wafer processing conditions

Resist:	AZ® 15nXT
Resist platform:	Negative-tone CA
Film thickness:	11.2 µm
Soft bake:	110°C x 180 sec
Pattern:	Contact holes, 72% coverage
Exposure dose:	900 mJ/cm ²
PEB:	120°C x 60 sec
Substrate:	8" HMDS-primed Silicon

Remover bath conditions

Temperature:	80°C
Volume:	150 mL in 250mL beaker
Agitation:	300 RPM stirring

Able to clean 11 wafers with 72% resist coverage by dissolution of resist in 150mL of Remover 910. This is equivalent to **>250 8" wafers with 81% resist coverage per gallon of Remover 910.**

SUMMARY

- Very effective at removing and dissolving negative-tone chemically amplified crosslinked resists
- Very effective at removing and dissolving positive-tone resists such as DNQ/Novolac and chemically amplified
- Low etch rates on many sensitive metals and other materials
- EH&S friendly product: Acceptable in Europe
 - No NMP, DMAC, DMSO, TMAH
- No intermediate rinse necessary: go directly to DIW rinse
- Suitable for use in batch immersion, batch spray, and Veeco tools



www.merckgroup.com

Disclaimer

Products are warranted to meet the specifications set forth on their label/packaging and/or certificate of analysis at the time of shipment or for the expressly stated duration. MERCK MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE REGARDING OUR PRODUCTS OR ANY INFORMATION PROVIDED IN CONNECTION THEREWITH. Customer is responsible for and must independently determine suitability of Merck's products for customer's products, intended use and processes, including the non-infringement of any third parties' intellectual property rights. Merck shall not in any event be liable for incidental, consequential, indirect, exemplary or special damages of any kind resulting from any use or failure of the products: All sales are subject to Merck's complete Terms and Conditions of Sale. Prices are subject to change without notice. Merck reserves the right to discontinue products without prior notice.

The information on our trademarks is available in the Trademarks section on www.merckgroup.com. Detailed information on our trademarks is also available via publicly accessible resources. All other trademarks are the property of their respective owners.

© 2021 Merck KGaA, Darmstadt, Germany and/or its affiliates.

